

## Department of Pesticide Regulation



#### **Backflow Prevention Regulatory Requirements and Policy**

Date Established March 28, 2001

Enforcement Letter ENF 01-12

**Distribution** 

**County Agricultural Commissioners** 

Referrals

If you have any questions pertaining to this document, please contact your

Senior Pesticide Use Specialist liaison.

**Approval** 

original signed by

Scott Paulsen, Chief

Pesticide Enforcement Branch

(916) 445-3914

**Background** 

This letter states the Department of Pesticide Regulation's (DPR) policy pertaining to backflow prevention requirements in Title 3 of the California Code of Regulations (3CCR) section 6610.

A properly placed and functioning backflow prevention device prevents ground and surface water contamination by stopping the backward flow of pesticides from the mix tank to the water source in the event of a water pump failure or a decrease in water pressure.

Continued on next page

**FLEX YOUR POWER!** The energy challenge facing California is real. Every Californian needs to take immediate action to reduce energy consumption. For a list of simple ways you can reduce demand and cut your energy costs, see our Web site at <www.cdpr.ca.gov>.

Continued

#### Prior Documentation

This letter supercedes:

- Manual of Procedural Guidance for Enforcement Personnel, pages 63-64.
- Any other previous policies, positions, or interpretations that may be in conflict.

#### Outside Water Source

For the purposes of 3CCR section 6610, an outside water source includes all sources of water except water stored in a reservoir tank that is owned or under the control of the pesticide applicator and/or the property operator.

Examples of reservoir tanks include mobile "nurse rigs", stationary water tanks (above or below ground), or reservoirs maintained exclusively for irrigation water. The reservoir tank must be separated from the original water source by an acceptable backflow prevention device.

#### Pesticide Label Requirements

U.S. Environmental Protection Agency (EPA) Pesticide Registration Notice 87-1 requires pesticide registrants to include specific equipment requirements on their pesticide product labels for the application of pesticides though irrigation systems (chemigation). Handlers must comply with all chemigation equipment requirements specified on the pesticide label, including the backflow prevention requirements. When connecting to a public water supply, pesticide labels require handlers to use a reduced-pressure zone, backflow preventer. Alternatively, they may discharge the water into a reservoir tank as long as they maintain an air gap between the public water source and the top of the reservoir. For all other water supplies, pesticide labels require handlers to use a single check valve, vacuum relief valve and low pressure drain. Handlers who comply with the backflow prevention requirements on the pesticide product labeling also meet the requirements of 3CCR section 6610.

Continued on next page

Continued

Acceptable Devices and Device Descriptions The device descriptions were taken from the American Society of Agricultural Engineer Standard titled "Safety Devices for Chemigation" (ASAE EP409.1 DEC97. Copyright © ASAE. All Rights Reserved.). 3CCR section 6610 does not include backflow prevention device standards nor does DPR approve backflow prevention devices or systems. The device descriptions are provided for your information and are advisory only.

Device	Description
Air-gap separation	ASAE description: An air gap is a physical
	separation between the free-flowing discharge end
	of a water pipeline and an open or non-pressurized
	receiving vessel. To have an acceptable air gap, the
	end of the discharge pipe must be located a distance
	of at least twice the diameter of the pipe above the
	topmost rim of the receiving vessel. In no case can
	this distance be less than 25 mm (1 inch).
Reduced pressure	ASAE description: This device consists of two
principle backflow	independently acting check valves, plus a pressure
prevention device	differential relief valve that is located between the
	two check valves. It can be used for both
	backsiphonage and backpressure control and can
	handle most toxic chemical chemicals. A minimum
	clearance of 300 mm (12 inches) above the ground
	level or grade is suggested to ensure an air gap
	between the relief valve and any water that might
	puddle beneath the device. If the relief valve is
	within 6.1 m (20 feet) of the water source, provide
	a trough or conduit to carry valve discharge away
	from the water source.
	This device is also identified as a "reduced-pressure
	zone, backflow preventer" on pesticide labels that
	allow handlers to connect chemigation systems to
	public water supplies.

Continued on next page

D 11 1 1 1	ACAD 1 ' .' TO 1 1 1 1 1 1
Double check valve	ASAE description: The double check valve
assembly	assembly is composed of two single, independently
	acting check valves and can handle both
	backsiphonage and backpressure. A low pressure
	drain and inspection port should be installed
	immediately upstream of this system (see #4 for
	equipment descriptions).
Single check valve,	ASAE description: This system is primarily an
vacuum relief valve	antisiphon device and should be constructed of
and low pressure	corrosion-resistant materials. The <u>check valve</u>
drain assembly	should be spring loaded with a chemically resistant
	sealing surface capable of preventing leakage.
	Generally, metal to metal surfaces would not be
	acceptable. The direction of flow should be clearly
	indicated on the outside of the device. The <u>vacuum</u>
	relief valve is installed on top of the pipe on the inlet
	side of the check valve to provide for vacuum relief
	when flow discontinues. The vacuum relief should
	be 19 mm (¾ inch) in diameter or sized according to
	ASAE Standard S376, Design, Installation and
	Performance of Underground, Thermoplastic
	Irrigation Pipelines, if underground thermoplastic
	pipeline is used. The <u>low-pressure drain</u> is for
	monitoring check valve performance and bleeding
	off any leakage. It must be located on the inlet side
	of the check valve at the lowest point, usually
	directly under the vacuum relief valve. The drain
	must be mounted in the pipe such that any check
	valve leakage enters the drain rather than flowing
	towards the water supply. The drain should be at
	least 19 mm (¾ inch) in diameter with a closing
	pressure of at least 7 kPA (1 psi) and not exceeding
	35 kPA (5 psi). If the drain is within 6 m (20 feet)
	of the water source, provide a trough or conduit to
	carry the drainage away, and grade the surface to
	assure drainage away from the water source.

Continued

An inspection port of at least 102 mm (4 inches) diameter should be provided to check for malfunction of the check valve and drain where the irrigation pipeline is 102 mm (4 inches) or larger. This inspection port can be combined with the mounting of the vacuum relief valve.

#### Device Placement

3CCR section 6610 requires pesticide handlers to equip service rigs and application equipment with acceptable backflow prevention devices before they draw water from an outside source. To prevent the accidental contamination of ground or surface water, a pesticide handler must properly install an acceptable, functioning backflow prevention device between the water source and the pesticide handling equipment. DPR policy allows pesticide handlers to install the backflow prevention device on the pesticide handling equipment or the water source provided they position and install it properly.

## **Functioning Devices**

3CCR section 6600, General Standards of Care, requires handlers to perform pest control in a careful and effective manner; and exercise reasonable precautions to avoid contamination of the environment. To prevent ground and surface water contamination, pesticide handlers must ensure that backflow prevention devices function properly whenever regulations require the use of this equipment. Pesticide handlers who use faulty or improperly installed backflow prevention devices violate the requirements of 3CCR section 6600 whether the pesticide application caused environmental contamination or not.

Continued on next page

Continued

Requirements beyond the scope of FAC or 3CCR 3CCR section 6610 states "Backflow protection must be acceptable to both the water purveyor and the local health department." This is an informational statement that notifies pesticide handlers and property operators that local health departments and/or water purveyors may require the use of certain types of backflow prevention devices. Pesticide handlers and property operators should check with these agencies before installing backflow prevention systems to assure compliance with applicable water protection requirements that are beyond the scope of the FAC.

DPR and the CACs are not authorized to enforce Health and Safety Code statutes or Title 17, Public Health, regulations pertaining to the protection of drinking water. 3CCR section 6610 does not oblige county agricultural commissioners to enforce regulatory requirements that are beyond the scope of their current authority.

The General Application of Standards, 3CCR section 6601 (b), states "it is not the intent of [3CCR] to require separate or duplicate equipment or facilities." A pesticide handler or property operator may use a backflow prevention device that meets the requirements of another regulatory agency provided the device also meets requirements established by DPR. In situations where the local health department or a water purveyor has clear authority over the acceptability of backflow prevention devices, DPR recommends that the CAC defer to those agencies. Where no other backflow prevention standards apply, handlers must comply with the requirements of 3CCR section 6610.

cc: Mr. Daniel J. Merkely, Agricultural Commissioner Liaison